



AVE-100 Firmware Upgrade V1.2.0 Instructions

I. Upgrade Instructions

- Press and hold the **Anti-Feedback** and **Recorder** keys while powering on the device to enter update mode.

Connect the device to your PC via a USB cable for firmware update.

- After connecting the device to the PC with a USB cable, click **Start** to begin the update.



II. Update Details

- Optimized microphone compression parameters to fix issues of instantaneous volume drop and abnormal gain during high-dynamic singing, delivering a more natural and consistent overall dynamic performance.
- Increased the maximum volume and decay value of reverb effects by approximately 20%, enhancing spatial presence to meet demands for heavier reverb.

- Optimized the latency and signal chain logic of AutoTune, improving real-time pitch correction response and stability.

Updated AutoTune with the **Electric** mode for better electrified vocal styles and faster pitch correction.

- Fixed the issue where chromatic and diatonic scales failed to take effect on AutoTune. Also improved the accuracy of Key Learning and the performance of the three harmony modes.